




COOKTOP PARTS

For Models: GR556LRKB0, GR556LRKC0, GR556LRKS0, GR556LRKP0
(Black) (Pure Biscuit) (Stainless) (True White)

30" Free-Standing
Self Clean Range
Heat & Cool



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

COOKTOP PARTS


For Models: GR556LRKB0, GR556LRKC0, GR556LRKS0, GR556LRKP0
(Black) (Pure Biscuit) (Stainless) (True White)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	12	4450934	Thermostat, Fixed	30		Trim, Cooktop
	LIT9755129	Installation Instructions	13	9780265	Screw			(Right Hand)
	LIT9755084	Use & Care Guide	14		Cooktop, Ceran	9755059PW		White
	LIT9755067	Tech Sheet		9755133CW	True White	9755059PB		Black
	LIT9755063	Wiring Diagram		9755133CB	Black	9755059PC		Biscuit
	LIT9755145	Quick Ref. Guide		9755133CC	Biscuit	9755059SS		Stainless
	LIT9752775	Template, Anti-Tip	15	9781459	Rod, Large			(Left Hand)
2	9754102	Gasket, Glass			Ceran Element	9755060PW		White
3	9755142	Deflec, Vent	16	9751871	Screw	9755060PB		Black
4		Gasket, Cooktop	17	341196	Thermo Disc	9755060PC		Biscuit
	9755093	Black		9780265	Screw(4)	9755060SS		Stainless
	9755118	Gray	18		Cover, Vent	32		Glass, Backsplash
5		Support, Element		9755391	Black	9755035PW		White
	9752892	B,T,S Models		9755393	Gray	9755035PB		Black
	9755331	P Model Only	19		Gasket, Vent Cover	9755035PC		Biscuit
6	9751629	Bracket, Pivot		9751841	Black	33	9781460	Rod, Small
	9752003	Washer, Pivot		9755184	Gray			Ceran Element
7	9781553	Brace, Support	20		Backsplash	34		Panel, Accent
8	9753691	Clip, Support (4)		9755038PW	White			With Badge Asy
9		Bumper, Rubber (4)		9755038PB	Black	9755455CW		White Model (P)
	9780771	Black		9755038PC	Biscuit	9755455CB		Black/Stls (B,S)
	9750969	White		9755038SS	Stainless	9755455CC		Biscuit Model (T)
10	9781936	Hot Light	21	9751984	Bimetal	35	98997	Clip, Wire
11		Element, Surface	23	9780272	Screw			
	8523697	1500W – LR	26	9755042	Cover, Backsplash			
	8523696	1800W – RF						
	8523694	2200W – RR						
	8523693	1000/2400W – LF						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR AND DRAWER PARTS

For Models: GR556LRKB0, GR556LRKC0, GR556LRKS0, GR556LRKP0
(Black) (Pure Biscuit) (Stainless) (True White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR AND DRAWER PARTS


For Models: GR556LRKB0, GR556LRKC0, GR556LRKS0, GR556LRKP0
(Black) (Pure Biscuit) (Stainless) (True White)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	9750676	Retainer, Glass	8		Handle, Door	31	3196161	Screw
2		Panel, Oven Door		9755066PW	White	32		Screw
		Left Side		9755066PB	Black		8533819	White
	9755031PW	White		9755066PC	Biscuit		8533825	Black
	9755031PC	Biscuit	9	9781449	Gasket, Door Glass (4)		8533820	Biscuit
	9755031PB	Black	10	9782033	Hinge, Door R or L		8533818	Bright Zinc
	9755031SS	Stainless	11	9781592	Glass, Baffle	33	9781771	Steam, Deflector
		Right Side	12	9781602	Frame, Glass	34		Cover, Lower
	9755032PW	White	13	9781586	Shield Door			Left Side
	9755032PC	Biscuit	14	9780771	Bumper, Rubber		9755036PW	White
	9755032PB	Black	15	9755138	Glass, Pyro		9755036PC	Biscuit
	9755032SS	Stainless	16	9755177	Seal, Glass		9755036PB	Black
3	9755092GM	Bracket, Vent Trim	18	9754006	Insulation		9755036SS	Stainless
4	9755039	Trim, Bottom Glass	19	9781600GM	Liner, Door			Right Side
5		Glass, Door	22	8523840	Insulation (2)		9755037PW	White
	9755064PW	White	24		Panel, Lower		9755037PC	Biscuit
	9755064PB	Black		9755034PW	White		9755037PB	Black
	9755064PC	Biscuit		9755034PB	Black		9755037SS	Stainless
6		Vent, Door		9755034PC	Biscuit	35		Panel, Lower Glass
	9755040PW	White	25	9750693	Heat Channel		9755068PC	Biscuit
	9755040PB	Black		90296	Clip		9755068PW	White
	9755040PC	Biscuit	28	9781502	Spacer, Door (8)		9755068PB	Black
			29	9780265	Screw			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

For Models: GR556LRKB0, GR556LRKC0, GR556LRKS0, GR556LRKP0
(Black) (Pure Biscuit) (Stainless) (True White)

For Models: GR556LRKB0, GR556LRKC0, GR556LRKS0, GR556LRKP0
(Black) (Pure Biscuit) (Stainless) (True White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN CHASSIS PARTS


For Models: GR556LRKB0, GR556LRKC0, GR556LRKS0, GR556LRKP0
(Black) (Pure Biscuit) (Stainless) (True White)

Illus. No.	Part No.	DESCRIPTION
1	9755576	Vent Box, Oven
2	9750514GM	Chassis, Front
3	9755116	Insulation, Wrap
4	9755117	Insulation, Rear
5	9755044GM	Oven Liner
6	9755179	Gasket Oven
7		Side, Oven L or R
	9782500PW	White
	9782500PB	Black
	9782500PC	Biscuit
8	9780664	Shield, Insulation
9	9751789	Fan Duct, Side
10	4454949	Block, Fuse
11	8523835	Burner Box
12	4454976	Fuse
13	9751653	Duct, Top
14	4453340	Support, Fan
15	8523034	Microcptr
16	9755390	Motor, Fan
17	9750147	Bottom Rail (2)
18	312701	Foot, (4)
19	9782005	Hinge, Door L or R
21	9755049	Side Duct
22	9755100	Shield, PCB
23	9755099	Bracket, PCB
24	4453668	Gasket, Duct
25	8523834	Vent, Tube
27	9755048	Rear Duct
29	9755192	Door Switch
31	9780578	Button, Plug
32	9755090	Microcptr
33	9782326	Shield, Heat
34	9782329	Fan Duct, Cover
35	9780265	Screw
36	9751808	Screw
38	9755055	Insulation
39	9755054	Insulation
41		Support
	4453362	Left Hand
	4453363	Right Hand
42	9755043	Bracket, Support

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models: GR556LRKB0, GR556LRKC0, GR556LRKS0, GR556LRKP0
(Black) (Pure Biscuit) (Stainless) (True White)



Illus. No.	Part No.	DESCRIPTION
1	4453681	Element, Broil
2	4453682	Element, Bake
3	3400968	Nut, Speed
4	9781050	Socket, Light
5	8935	Bulb, Oven
6	9755047	Retainer, Insulation


Illus. No.	Part No.	DESCRIPTION
8	9781543	Assembly, Fan
9	9751904GM	Baffle, Convection
15	9781509	Screw
18	420104GM	Grill, Broiler
19	420101GM	Pan, Broiler
20	9750827	Rack, Roasting

Illus. No.	Part No.	DESCRIPTION
21	9750823	Rack, Standard
22	9782081	Sensor
23	3196168	Screw
24	9780272	Screw
26	3184533	Gasket, Lens
27	9781049	Lens, Light

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REAR CHASSIS PARTS

For Models: GR556LRKB0, GR556LRKC0, GR556LRKS0, GR556LRKP0
(Black) (Pure Biscuit) (Stainless) (True White)



Illus. No.	Part No.	DESCRIPTION
1	9751051	Back panel, Chassis
2	9752344	Box, Terminal
3	9751353	Panel, Rear Cover
4	9752345	Cover, Terminal Box
5	9755146	Suppressor, Trans
6	9780272	Screw
7	9782611	Oven Lock Assembly


Illus. No.	Part No.	DESCRIPTION
11	9780265	Screw
12	9754291	Switch, Interloc
13	9750887	Screw
14	9750888	Nut
15	9750523	Rod, Lock
17	258076	Terminal Block

Illus. No.	Part No.	DESCRIPTION
18	3169573	Ground Strap
	313660	Clip, (1)
19	9755575	Vent Back, Oven
20	3400016	Screw
21	423247	Screw
22	112432	Nut
23	690989	Screw, Grounding

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

COOLING PARTS

For Models: GR556LRKB0, GR556LRKC0, GR556LRKS0, GR556LRKP0
(Black) (Pure Biscuit) (Stainless) (True White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

COOLING PARTS


For Models: GR556LRKB0, GR556LRKC0, GR556LRKS0, GR556LRKP0
(Black) (Pure Biscuit) (Stainless) (True White)

Illus. No.	Part No.	DESCRIPTION
1	4453356	Box, Evap (Right)
2	4453437	Box, Evap (R.H. Adapter)
3	4453359	Blade, Fan (2)
4	4453357	Motor, Fan
5	8533832	Screw
6	4453435	Spacer, Motor
7	9755627	Compressor
8	4453366	Tube, Discharge
9	4453367	Tube, Discharge (W/ Dryer)
10	8011446	Clip (4)
11	950212	Grommet (4)
12	4453368	Tube, Charge
13	4453352	Housing, Fan (Condenser)
14	4453346	Plate, Base
15	4453353	Pan, Drain
16	4453375	Spacer (2)
17	4453347	Spacer, Evap
18	2217223	Overload
19	4453376	Tube, Suction
20	9755626	Relay & Capacitor Assembly (Includes #21)
21	2208371	Cover, Terminal
22	4453436	Box, Evap (L.H. Adapter)
23	4453348	Evaporator/Cndensr
24	4453358	Housing, Fan (Evap)
25	4453361	Box, Evap (Top)
26	4453337	Sleeve
27	4453686	Dual Cntl, Bimetal
28	4453355	Box, Evap (Left)
29	9755052	Insulation, Rear Cooling
30	9755053	Insulation, Front Cooling Module
31	8533833	Screw
32	9755152	Tube, Drain
33	9782493	Shield, Baffle
34	9782494	Shield, Fence
35	9782507	Shield, Fan
36	4453657	Clip, Standoff
37	4453666	Seal, Rear
38	4453654	Seal, Side
39	4453677	Bracket, Top
40	9755119	Bracket, Hold Down
41	9755123	Seal, Front Side
42	9755122	Rivet, Plastic
43	9755150	Grommet
44	9755154	Grommet, Sq Btm

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: GR556LRKB0, GR556LRKC0, GR556LRKS0, GR556LRKP0
(Black) (Pure Biscuit) (Stainless) (True White)



Illus. No.	Part No.	DESCRIPTION
1	9755591CW	Console / Membrane White
	9755591CB	Black
	9755591CC	Biscuit
	9755591CS	Stainless
3	3196068	Lens, Light-Ind
8	9755065FW	Knobs, Control White
	9755065FB	Black
	9755065FC	Biscuit
10	9782613	Microcptr
21	9750638	Switch, Infinite 1500W – LR
	9750639	1700W – RF
	9750641	2100/2600 W
	9755173	1000/2400W – LF
22	9780271	Screw
23	3400853	Screw
24	9780265	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MISCELLANEOUS PARTS

For Models: GR556LRKB0, GR556LRKC0, GR556LRKS0, GR556LRKP0
(Black) (Pure Biscuit) (Stainless) (True White)

Illus. No.	Part No.	DESCRIPTION
---------------	-------------	-------------

SPLICING WIRES--25FT.

LENGTH

242828	Wire, Black
	12 Ga. 150°c
242820	Wire, Black
	14 Ga. 150°c
242821	Wire, Blue
	14 Ga. 150°c
242822	Wire, Brown
	14 Ga. 150°c
242830	Wire, Brown
	14 Ga. 200°c
242823	Wire, Green
	14 Ga. 150°c
242824	Wire, Orange
	14 Ga. 150°c
242825	Wire, Red
	14 Ga. 150°c
242831	Wire, Red
	14 Ga. 200°c
242827	Wire, Yellow
	14 Ga. 150°c
242832	Wire, Yellow
	14 Ga. 200°c

PAINT, TOUCH-UP (1/2oz.)

72017	White
72107	Almond
511873	White Porcelain
	(2 Oz.)
4392899	Biscuit

NOTE: Cooktop Surface is Porcelain; All Other Panels are Painted Surfaces.

Illus. No.	Part No.	DESCRIPTION
---------------	-------------	-------------

PAINT, PRESSURIZED SPRAY (12 oz.)

350930	White
350956	Almond
285006	Superior Black
206922	Primer (White)
4392901	Biscuit

PAINT, BULK (1 qt.)

799344	White (Uncut)
978883	Almond (Uncut)
4392900	Biscuit (Uncut)

REFINISHING MATERIAL

799832	Kit, Porcelain
	Repair
	(White)
242756	Touch-Up
	Self-Clean (1/2 Pt.)

CLEANER, COOKTOP

9780196	Glass Cleaner
---------	---------------

ANTI-TIP KIT

9751745	Anti-Tip Kit
---------	--------------

Illus. No.	Part No.	DESCRIPTION
---------------	-------------	-------------

WIRING HARNESS PARTS

9755101	Harness, Wire
	(Main Harness)
9755121	Harness, Wire
	(Control, Ceran)
9755103	Harness, Wire
	(Console)
9755108	Harness, Wire
	(Cooktop)
9755193	Harness, Wire
	(Oven Door)
9755120	Harness, Wire
	(Fan/BMS)
9755136	Harness, Wire
	(Light-Simmer)
9782182	Harness, Wire
	(Dual Switch)
9755107	Harness, Wire
	(Dbl Line Brk)
9782111	Wrap, Tie
90016	Clip
9755107	Harness, Wire
	Dbl Line Break
4453365	Harness, Wire
	(Cooling Module)
20082084	Tie, Wire
9755140	Clip, Harness
690989	Screw, Ground